




YOUR CONSTRUCTION TECHNOLOGY PROVIDER

# Field Reference Guides

EARTHWORKS DOZER VERISON 2.10

[SITECH SOUTHEAST TEXAS](#)

[SITECH-SETX.COM](http://SITECH-SETX.COM)



## System: Earthworks Dozer


Version: 2.1

### **Table of Contents**

### **Page #**

<input type="checkbox"/> Starting Earthworks	3
<input type="checkbox"/> Dashboard	4
<input type="checkbox"/> Select Project and Design	5
<input type="checkbox"/> Select Project and Design: VCL	7
<input type="checkbox"/> Create Project	8
<input type="checkbox"/> Earthworks Screen	9
<input type="checkbox"/> Work Screen Interface	10
<input type="checkbox"/> Work Screen Setup	11
<input type="checkbox"/> Text Ribbon Setup	13
<input type="checkbox"/> Blade Focus Point / Vertical Guidance	14
<input type="checkbox"/> Import Data USB	15
<input type="checkbox"/> Export Data USB	16
<input type="checkbox"/> Cutting Edge Wea / Overcut protection	17
<input type="checkbox"/> Verify System Accuracy	18
<input type="checkbox"/> Vertical Offset / Memories	19
<input type="checkbox"/> Horizontal Offset	21
<input type="checkbox"/> Cut Fill Mapping	22
<input type="checkbox"/> Record Point	23
<input type="checkbox"/> Delete / Edit Point	24
<input type="checkbox"/> Navigate to Point	25
<input type="checkbox"/> Lane Guidance	26
<input type="checkbox"/> Surface Manager	27
<input type="checkbox"/> Linework Manager	28
<input type="checkbox"/> UTS Setup	29
<input type="checkbox"/> Change Radio Network	31
<input type="checkbox"/> Level Surface	32
<input type="checkbox"/> Sloping Surface	33
<input type="checkbox"/> Laser Setup	35


## Starting Earthworks




1. Touch  Earthworks Icon



2. Select operator  
3. Enter password if required and touch login




4. Raise and lower the blade to initialize sensors



5. Touch Start

## Dashboard




### Machine Setup



- Position Source
- Correction Source

### System Status



- Status of Devices
- Component Warnings

### Job Setup



- Select or Create Project
- Select or Create Design
- Create Work Orders


### Licenses




- EC520 License
- TD520 License
- GNSS Receiver License

# SITECH TECHNOLOGY DEALER Field Reference Guides

## Select Project, Design and Work Order




1. Touch Job Setup




2. Select Project  
3. Select Mode


4. Work Order (Create New)




5. Touch Add Work Order



6. Type in New Work Order Name  
7. Touch Save




8. Select Design  
9. Touch Apply




10. Touch Start


## Select Project, Design, and Work Order: VCL




1. Touch Job Setup




2. Touch Project- Select Site VCL



3. Touch Design- Select SiteVCL




4. Touch Surface- Select Surface




5. Touch Master Alignment- Select Road CL  
6. Touch Apply

## Create Project




1. Touch Job Setup




2. Touch Project




3. Touch Create



4. Enter Project Name  
5. Touch Save



6. Touch Select



7. Touch Apply  
8. Touch Start









## Earthworks Screen

6







## Work Screen Interface




1. Touch Start




2. 2 Finger swipe to change views




3. Drag to pan  
4. Pinch-Spread to zoom



5. Touch to select Pan or Rotate




6. Touch to re-center



7. Touch and Hold for Setup  
8. Swipe to change view


## Work Screen Setup




1. Touch and hold
2. Touch Layout




3. Touch Cross Section
4. Touch Profile View
5. Touch Plane View
6. Touch Done




7. 2 Finger Swipe to single view



8. Touch and Hold
9. Touch Layout




10. Touch 3D View
11. Touch Done




12. 2 Finger swipe to 2 Screen View

## Work Screen Setup Cont:



- 13. Touch and Hold
- 14. Touch Layout




- 15. Touch Cross Section View
- 16. Touch Profile View
- 17. Touch Done

## Text Ribbon Setup



1. Touch and Hold Text Ribbon




2. Touch each Text Item

- Cut/Fill Left
- Offline
- Station
- Cut/Fill right
- Northing
- Easting
- Elevation
- Design Elevation
- Design Cross Slope
- Design Mainfall
- Vertical GNSS Precision
- Satellite Count


3. Touch-Hold-Drag to change position

4. Touch Done


## Blade Focus Point / Vertical Guidance




1. Touch and Hold Blade Icon



- 2. Touch Focus Option
- 3. Touch Vertical Guidance Option
- 4. Touch Apply




5. Touch Blade Icon to change focus point




**NOTE:** "LINK TO FOCUS" vertical guidance will follow focus point.


## Import Data With USB




Insert USB  
1. Touch Next



2. Touch USB  
3. Touch Select




4. Touch “v”



5. Touch Earthworks Data  
6. Touch Project  
7. Touch Import




8. Touch OK




9. Touch Cancel  
Remove USB




## Export Data With USB



**Insert USB**  
1. Touch Transfer Type




2. Touch Export Files




3. Touch Next




4. Touch USB  
5. Touch Select




6. Touch "V"



7. Touch Earthworks Data  
8. Touch Projects  
9. Touch Export




10. Touch OK




11. Touch Cancel  
Remove USB


## Cutting Edge Wear and Overcut Protection




1. Touch and hold Focus Icon




2. Touch Edit




- 3. Measure A to B
- 4. Enter Length A and B
- 5. Touch Save



6. Keep the Blade still, let sensors initialize



- 7. Touch Advanced Options
- 8. Touch Overcut Protection




9. Touch Apply

## Verify System Accuracy

Verify the system accuracy by checking into a bench



Position the blade tip over the bench point




1. Swipe ribbon to view, Northing, Easting, Elevation
2. Touch blade focus to match verification location


3. Verify Accuracy Northing, Easting, Elevation

See Supervisor if Northing, Easting and Elevation do not match Project tolerances

## Vertical Offset / Memories




1. Touch and hold Vertical Offsets



2. Enter Offset  
3. Touch Apply to use immediately




4. Touch and Hold Vertical Offsets



5. Touch memories



6. Touch Add




7. Enter Description  
8. Enter value  
9. Touch Save

## Vertical Offset / Memories Cont:




10. Select Memory  
11. Touch Done




12. Touch Apply


## Horizontal Offset




1. Touch and hold Horizontal Offset




2. Touch Select Alignment




3. Touch Line OR  
4. Touch and Select Alignment





5. Touch Select



8. Enter Offset Value  
9. Touch Apply




## Cut Fill Mapping




1. Two Finger Swipe to 3 screen view
2. Touch Mapping Icon to View

**\*\*Cut Fill Mapping will only be visible in Plan, Cross section, and Profile views\*\***


## Record Point




1. Touch and Hold Record Point




2. Touch to Edit Name  
3. Touch and select Work Order



4. Select Work order for point location  
5. Touch done



6. Type in Code  
7. Touch Save




8. Touch Point Icon Records Point


**\*\* Note- After recording a point, it will save automatically in Work Order Created during project setup. \*\***




## Delete / Edit Point




1. Touch and hold over point created




2. Touch point information




3. Edit point information if needed  
4. Touch Delete




5. Touch Yes to Confirm Delete  
(once deleted can no longer retrieve)




## Navigate to Point




1. Touch and hold next to point



2. Touch Point Name




3. Touch Navigate To Point




4. Touch to Exit


## Lane Guidance




1. Touch and hold Lane Guidance



2. Touch an Alignment  
3. Touch Next




4. Touch Alignment A  
5. Touch Alignment B  
6. Touch Apply



7. Touch Lane Guidance to Cancel

The slope between the two lines will be projected


## Surface Manager \*\* Will only work in VCL format Designs\*\*



1. Touch work settings




2. Touch Surface Manager



- 3. Select Surface for guidance
- 4. Select which Reference Surface(Maximum of 2)
- 5. Touch Apply


## Linework Manager \*\* Will only work in VCL format Designs\*\*



1. Touch Work Settings




2. Touch Linework manager




- 3. Zoom In/Out on design
- 4. Can select all linework
- 5. Select Individual linework
- 6. Touch apply once complete

## UTS Setup




1. Touch Machine Setup




2. Touch Positioning Source

3. Touch UTS




4. Touch to Edit/Add UTS




5. Select Channel/ID/Target ID

6. Touch Next




7. Touch to Start




8. Touch to use for guidance


## UTS Setup Cont:



9. Touch Done




10. Touch Apply




11. Touch Start




## Change Radio Network



1. Touch System Settings




2. Touch GNSS Correction Source




3. Touch Radio Network  
4. Touch Set




## Level Surface




1. Touch Work Settings




2. Touch Job Setup




3. Touch Mode and Select Depth and Slope  
4. Touch Apply




5. Touch Bench Heading




6. Select Blade Tip Focus Point  
7. Place Blade Tip at Elevation and Touch Bench




## Sloping Surface




1. Touch Work Settings




2. Touch Job Setup




3. Touch Mode and Select Depth and Slope  
4. Touch Apply



5. Touch Bench Heading




6. Select Blade Tip Focus Point  
7. Place Blade Tip at Elevation and Touch Bench




8. Touch and Hold Target Mainfall  
**Note:** This will apply a slope parallel to the direction of heading.


## Sloping Surface Cont:




- 9. Enter Mainfall Slope
- 10. Touch Apply




- 11. Touch and Hold Cross Slope  
**Note:** This will apply a slope perpendicular to the direction of the heading




- 12. Enter Cross Slope
- 13. Touch Apply




## Laser Setup




1. Touch Machine Setup




2. Touch Positioning Source  
3. Touch 2D




4. Touch to Edit 2D Sensors



5. Touch 2D Type  
6. Touch Apply



7. Touch Start



8. Touch to bench Laser Receivers