




YOUR CONSTRUCTION TECHNOLOGY PROVIDER

Field Reference Guides

EARTHWORKS GRADER VERISON 2.00

SITECH SOUTHEAST TEXAS

SITECH-SETX.COM



System: Earthworks Grader


Version: 2.0

Training Guides


Page #

<input type="checkbox"/> Starting Earthworks	3
<input type="checkbox"/> Dashboard	4
<input type="checkbox"/> Select Project, Design and Work Order	5
<input type="checkbox"/> Select Project, Design and Work Order: VCL	6
<input type="checkbox"/> Create Project	7
<input type="checkbox"/> Earthworks Screen	8
<input type="checkbox"/> Work Screen Interface	9
<input type="checkbox"/> Work Screen Setup	10
<input type="checkbox"/> Text Ribbon Setup	12
<input type="checkbox"/> Blade Focus Point / Vertical Guidance	13
<input type="checkbox"/> Import Data USB	14
<input type="checkbox"/> Export Data USB	15
<input type="checkbox"/> Cutting Edge Wear/Overcut protection	16
<input type="checkbox"/> Select Bolt Hole	17
<input type="checkbox"/> Verify System Accuracy	18
<input type="checkbox"/> Vertical Offset / Memories	19
<input type="checkbox"/> Horizontal Offset	21
<input type="checkbox"/> Cut Fill Mapping	22
<input type="checkbox"/> Record Point	23
<input type="checkbox"/> Delete / Edit Point	24
<input type="checkbox"/> Navigate to Point	25
<input type="checkbox"/> Lane Guidance	26
<input type="checkbox"/> Surface Manager	27
<input type="checkbox"/> Linework Manager	28
<input type="checkbox"/> UTS Setup	29
<input type="checkbox"/> Change Radio Network	31
<input type="checkbox"/> Level Surface	32
<input type="checkbox"/> Sloping Surface	33


Starting Earthworks




1. Touch  Earthworks Icon



2. Select operator
3. Enter password if required and touch login




4. Raise and lower the blade to initialize sensors



5. Touch Start

Dashboard




Machine Setup



- Position Source
- Correction Source

System Status



- Status of Devices
- Component Warnings

Job Setup



- Select or Create Project
- Select or Create Design
- Create Work Orders


Licenses




- EC520 License
- TD520 License
- GNSS Receiver License

SITECH TECHNOLOGY DEALER Field Reference Guides

Select Project, Design and Work Order




1. Touch Job Setup




2. Select Project
3. Select Mode


4. Work Order (Create New)




5. Add Work Order



6. Type New work Order Name
7. Touch Save




8. Select Design
9. Touch Apply




10. Touch Start


Select Project, Design and Work Order: VCL




1. Touch Job Setup




2. Touch Project- Select Project
3. Touch Mode- Select Design
4. Touch Work Order




5. Add Work Order



6. Type New work Order Name
7. Touch Save



8. Touch Design- Select Design that contains a VCL
9. Touch Surface- Select Surface



10. Touch Master Alignment - Select Alignment
11. Touch Apply




12. Touch Start


Create New Project




1. Touch Job Setup



2. Touch Project




3. Touch Create



4. Enter Project Name
5. Touch Save




6. Touch Select




7. Touch Apply
8. Touch Start




Earthworks Screen




Work Screen Interface



1. Touch to Start




2. 2 Finger swipe to change views




3. Drag to pan


4. Pinch-Spread to zoom/Zoom out



5. Touch to select Pan or Rotate




6. Touch to re-center




7. Touch and Hold for Setup

8. Swipe to change view


Work Screen Setup




1. Touch and Hold
2. Touch Layout




3. Touch Cross Section
4. Touch Profile View
5. Touch Plan View
6. Touch Done




7. 2 Finger Swipe to single view



8. Touch and Hold
9. Select Layout




10. Touch 3D View
11. Touch Done




12. 2 Finger swipe to 2 Screen View

Work Screen Setup Cont:




- 13. Touch and Hold
- 14. Touch Layout




- 15. Touch Cross Section View
- 16. Touch Profile View
- 17. Touch Done

Text Ribbon Setup



1. Touch and Hold Text Ribbon




2. Touch each Text Item

- Cut/Fill Left
- Offline
- Station
- Cut/Fill right
- Northing
- Easting
- Elevation
- Design Elevation
- Design Cross Slope
- Design Mainfall
- Vertical GNSS Precision
- Satellite Count


3. Touch-Hold-Drag to change position

4. Touch Done

Blade Focus Point / Vertical Guidance




1. Touch and Hold Blade Icon




2. Touch Focus Option

3. Touch Vertical Guidance Option

4. Touch Apply




5. Touch Blade Icon to change focus point




NOTE: "LINK TO FOCUS" vertical guidance will follow focus point.


Import Data With USB




Insert USB
1. Touch Next



2. Touch USB
3. Touch Select




4. Touch “v”



5. Touch Earthworks Data
6. Touch Project
7. Touch Import




8. Touch OK




9. Touch Cancel
Remove USB


Export Data With USB



Insert USB
1. Touch Transfer Type




2. Touch Export Files




3. Touch Next




4. Touch USB
5. Touch Select




6. Touch "V"



7. Touch Earthworks Data
8. Touch Projects
9. Touch Export



10. Touch OK




11. Touch Cancel
Remove USB


Cutting Edge Wear / Overcut Protection




1. Touch and hold Focus Icon




2. Touch Edit




- 3. Measure A & B
- 4. Enter measured length A and B
- 5. Touch Save



6. Sensors will Initialize




- 7. Touch Advanced Options
- 8. Touch Overcut Protection




9. Touch Apply


Select Bolt Hole



1. Touch and hold on Blade Manager Icon



2. Touch Current Bolt Hole



3. Touch Desired Bolt Hole

4. Touch Apply


****Note machine must be measured up for additional bolt holes.****

Verify System Accuracy


Verify the system accuracy by checking into a bench



Position the blade tip over the bench point




1. Swipe ribbon to view, Northing, Easting, Elevation
2. Touch blade focus to match verification location




3. Verify Accuracy Northing, Easting, Elevation

See Supervisor if Northing, Easting and Elevation do not match Project tolerances


Vertical Offset / Memories




1. Touch and hold Vertical Offsets




2. Enter Offset
3. Touch Apply to use immediately




4. Touch and Hold Vertical Offsets



5. Touch memories




6. Touch Add




7. Enter Description
8. Enter value
9. Touch Save

Vertical Offset / Memories Cont:




10. Touch Memory
11. Touch Done




12. Touch Apply

Horizontal Offset




1. Touch and hold Horizontal Offset




2. Touch Select Alignment




3. Touch Line OR
4. Touch and Select Alignment





5. Touch Select



8. Enter Offset Value
9. Touch Apply




Cut Fill Mapping




1. Two Finger Swipe to 3 screen view
2. Touch Mapping Icon to View

****Cut Fill Mapping will only be visible in Plan, Cross section, and Profile views****


Record Point




1. Touch and Hold Record Point




2. Touch to Edit Name
3. Touch and select Work Order



4. Touch Work order for point location
6. Touch done




7. Type Code
8. Touch Save




8. Touch Point Icon Records Point

**** Note- After recording a point, it will save automatically in Work Order Created during project setup. ****


Delete / Edit Point:




1. Touch and hold over point created




2. Touch point information




3. Can Edit point information if needed
4. Touch Delete




5. Touch Yes to Confirm Delete
(once deleted can no longer retrieve)




Navigate to Point




1. Touch and hold on Point



2. Touch Point Info




3. Touch Navigate to Point




4. Touch Stop icon once complete


Lane Guidance




1. Touch and hold Lane Guidance



2. Touch an Alignment
3. Touch Next




4. Touch Alignment A
5. Touch Alignment B
6. Touch Apply




7. Touch Lane Guidance to Cancel

The slope between the two lines will be projected


Surface Manager ** Will only work in VCL format Designs**



1. Touch work settings




2. Touch Surfaces Manager




- 3. Surface for guidance
- 4. Touch which Reference Surface(Maximum of 2)
- 5. Touch Apply


Linework Manager ** Will only work in VCL format Designs**



1. Touch Work Settings




2. Touch Linework manager




- 3. Zoom In/Out on design
- 4. Can select all linework
- 5. Select Individual linework
- 6. Touch apply once complete


UTS Setup




1. Touch Machine Setup




2. Touch Positioning Source
3. Touch UTS (Right or Left)




4. Touch to Edit/Add UTS



5. Select Channel/ID/Target ID
6. Touch Next




7. Touch to Start




8. Touch to use for guidance


UTS Setup Cont:



9. Touch Done




10. Touch Apply




11. Touch Start




Change Radio Network



1. Touch System Settings




2. Touch GNSS Correction Source




3. Touch Radio Network

4. Touch Set


Level Surface




1. Touch Work Settings




2. Touch Job Setup




3. Touch Mode and Select Depth and Slope
4. Touch Apply




5. Touch Bench Heading




6. Touch Blade Tip Focus Point
7. Place Blade Tip at Elevation and Touch Bench




Sloping Surface



1. Touch Work Settings




2. Touch Job Setup




3. Touch Mode and Select Depth and Slope

4. Touch Apply




5. Touch Bench Heading




6. Select Blade Tip Focus Point

7. Place Blade Tip at Elevation and Touch Bench




8. Touch and Hold Target Mainfall


Sloping Surface Cont:



- 9. Enter Mainfall Slope
- 10. Touch Apply



- 11. Touch and Hold Cross Slope



- 12. Enter Cross Slope
- 13. Touch Apply

